

## SAFETY PRECAUTIONS

1. The device must be installed by a qualified person.
2. Disconnect all power before working on the device. Don't touch any terminal when the power is ON.
3. Verify correct terminal connection when wiring.
4. Don't dismantle or repair the device whether it operates normally, otherwise no responsibility is assumed by producer and seller.
5. Never use the device at the site which can be invaded by corrode gas, strong sunshine light and rain.
6. Clean the device with a dry cloth.
7. Fail to follow these instructions will result in serious injury or death.

## FEATURES


- Microcontroller based
- 3 digit display for operating voltage and current value
- Protect electrical device against over/under voltage, overcurrent and short circuit faults
- Password settable by user
- Operating current setting by keys
- LEDs indication for output and faults state.
- 2 Module, DIN Rail mounting

## TECHNICAL DATA

| Models                           | MB2-22A       | MB2-63A |
|----------------------------------|---------------|---------|
| Rated current                    | 2A-22A        | 16A-63A |
| Rated supply voltage             | AC 220V, 50Hz |         |
| Operation voltage range          | AC 100V~400V  |         |
| Overvoltage(U>) trip value       | 220V~300V     |         |
| Undervoltage(U<) trip value      | 140V~210V     |         |
| Start delay                      | 5~100s        |         |
| Recovery time for overload fault | 1~100s        |         |
| Overvoltage trip time            | 0.5s          |         |
| Undervoltage trip time           | 0.5s          |         |
| Rated insulation voltage         | 400V          |         |
| Output contact                   | 1NO           |         |
| Protection degree                | IP20          |         |
| Altitude                         | ≤2000m        |         |
| Operating temperature            | -20 C~55 C    |         |
| Storage temperature              | -30 C~70 C    |         |

| Parameter       | Setting range | Step | Default setting            |
|-----------------|---------------|------|----------------------------|
| I <sub>tr</sub> | MB2-22        | 0.2  | 20A(MB2-22)<br>50A(MB2-63) |
|                 | MB2-63        |      |                            |
| U <sub>rH</sub> | 220V~300V     | 1    | 250                        |
| U <sub>rL</sub> | 140V~210V     | 1    | 170                        |
| t <sub>on</sub> | 5~100         | 1    | 5                          |
| t <sub>R</sub>  | 1~100         | 1    | 90                         |
| PR5             | 000~999       |      | !!!                        |

## FRONT-FACE PANEL



# MB2 SERIES

# SPARK


## ELECTRONIC CIRCUIT BREAKER

Please read complete instructions prior to installation and operation of the device.

### ● Faults code

|     |   |
|-----|---|
| U   | Overvoltage fault: input voltage is higher setting value  |
| U   | Undervoltage fault: input voltage is lower than setting value   |
| o-L | Overload fault: input current is higher than 1.1xIset   |
| --- | Short circuit fault: input current is higher than short circuit current value.  |
| Err | Continuous faults: If three continuous overload or short circuit faults occurred, the relay need to be reset with power switch after eliminated the faults. |

### ● Display for operating voltage and current




- Press  $\nabla$   $\blacktriangle$  keys to check operating voltage and current.
- After checked operating voltage and not press any keys for 5s, the device will exit automatically and display operating current. The display for operating current value is prior.

## OPERATION

1. Turn power switch on and start the device, setting current value displays.
2. User can input the password and enter setting.
3. If no faults are detected after energization, the contact closes and output indication LED lights up.
4. When overload fault is detected, overcurrent indication LED flashes and the display will show corresponding faults code.

## WIRING DIAGRAM



● Main menu setting



● Main display



>2s



● Input password and enter setting menu.

Press (M) key to set the parameters.



confirm




● Overcurrent trip value setting

Press (M) key to set the parameters.



● Overvoltage trip value setting

Press (M) key to set the parameters.



● Undervoltage trip value setting

Press (M) key to set the parameters.



● Start delay setting

Press (M) key to set the parameters



● Recovery time(for overload fault) setting

Press (M) key to set the parameters



● Password setting

Press (M) key to set the parameters



● Finish settings and press (M) to exit

- Press (M) to enter parameters setting. Confirm the settings and return to main menu by pressing (M) key again.
- Long press (▲) (▼) can increase or decrease rapidly.
- The relay will automatically exit from the menu and not save the modified value if not pressing the keys for continuous 60s during setting.

DIMENSIONS

