1. For simmering of delicate foods, and thickening sauces, etc.
2. Slow cooking.
3. For simmering Large Quantities.
4. Shallow frying of meat and pan dishes.
5. To bring all dishes to rapid heat.
6. To bring all dishes to a boil.

Note: the Lamp will go off when the hot plate reaches the selected temperature, and will code on and off to maintain the temperature.

## For your safety

When using your hot plate, basic safely precautions should always be followed Including the following:

1. Never Immerse the hot plate In water or any other Liquid.
2. Oil and fat being heated are not to be Left unattended without adult supervision.
3. Do not touch the surfaces or the hot plate when In operation, as they get hot.
4. The hot plate Is designed only for the heating and cooking of food, and must only be used with cooking utensils placed on It.
5. The hot plate must be turned to"0"setting and disconnected from the power outlet when out In use.
6. Cooking utensils, regardless of their size, should not project beyond the hot plate or Intrude Into the area of close proximity of the controls.
7. It Is dangerous to operate any electrical product with a damaged cord or plug, or aster the product malfunctions or Is dropped or damaged In any manner. Return the complete product to the place of purchase for Inspection and repair.

## How to care for your hot plate

1. Disconnect the hot plate from the power outlet.
2. Do not Immerse the hot plate In any Liquid.
3. Do not allow the cord to touch any hot surfaces of the hot plate.
4. Clean the painted surface with a damp soft cloth and mild household cleaning powder.
5. Baked on marks on the circular hot plate can be removed with a household cleaning powder. tum the unit on for a moment to dry after cleaning.
6. Commercially available hot plate cleaners are recommended to preserve the natural finish of the hot plate.



# JAMAKY




# Hot Plate

## JMK7013

220-240V~ 50/60Hz 2000W

GB:

# ENGLISH

## Before first use

Read and follow all the Instructions In this "use and care" even If you feel you are familiar.
With the product, and find a place to Keep It handy for future reference.
Your attention Is drawn particularly to the sections concerning "Important safeguards" .
Note: the rating of this product (as marked on the product identification plate) Is based on specific Loading tests. normal use or the use of other recommended attachments may draw significantly Less power.

## Important safeguards

When using any electrically powered product, basic safety precautions should always be followed Including the following:
Please read all Instructions c are fully before using the product.
Waning = to reduce the risk of fire, electrical shock or Injury to persons or property:
1. Always operate the product from a power source of the same Voltage, frequency and rating as Indicated on the product identification plate.
2. Close supervision Is necessary when the product Is used by or near children or Invalids. do not allow children to use It as a toy.
3. Do not operate any product with a damaged cord or plug, or after the product malfunctions. or is dropped or appears damaged In any way. Rectum the complete product to the place of purchase for Inspection, repair or replacement.
4. To reduce the risk of f.lectrice shock, do not Immerse or expose the product or flexible cord to rain, moisture or any Liquid other than those necessary for correct operation of the product.
5.This product should not be used In the Immediate Vicinity of water, such as bathtub, washbowls, swimming pool etc. where the Likelihood of Immersion or splashing could occur.
6. Do not operate or place any part of this product on or near any hot surfaces (such as a gas or electric burner or hot plate or





In a heated oven).
7. Switch off and unpin: from outlet when not In use, before assembling or disassembling parts and before cleaning. remove by grasping the plug-do not pull on the cord.
8 avoid contacting hot surfaces.
9. Do not use the appliance for other than Its Intended use.
10. Do not Leave the appliance unattended when switched on.
11. Using attachments or accessories not recommended or sold by the product distributor may cause personal or property hazards or Injuries.
12. This product Is Intended for normal domestic/household use only.

## Read and save these Instructions

**How to use your hot plate**

Before using your hot plate for the first time, tum the hot plate on the highest setting for 3 to 5 minutes to condition the protective coating. this should be the only time the hot plate Is tuned on without a cooking utensil on it.
For the most efficient operation of your hot plate the cooking utensils used should have a solid base and be as even as possible, and with a diameter of approx. 18 to 20 cm and a maximum capacity of 1.5lites (1500 watts hot plate), and a diameter of approx. 15 ta 17 cm and a maximum capacity of 1lites (800 watts hot plate). the base diameter of cooking utensils smaller than the diameter of the hot plate should not be used.
Cooking utensils, regardless of their size, should not project beyond the hot plate or Intrude Into the area of close proximity of the controls. utensils with convex, concave or uneven bottoms should not be used.

## Operation of control

Turn the controls to the recommended position marked to achieve the desired temperature. use this guide as a reference.
Note: both hot plates can be used at the same time, however care must be exercised to prevent the cooking utensil handles from protruding over the adjacent hot plate.
Important: when not In use, always tum the controls to the "0" position and disconnect from the power outlet.