














Golden Light

## LED WALL LAMP INSTRUCTION LETTER

Model	Power	FRAME COLOR	Color	Size (mm)	Luminous Flu	Voltage	Picture
JL171101 5W IP65	5W	BLACK	3000K	150*65*150	500LM	85V-265V	
SH-202 3W IP65	3W	BLACK	3000K	81*63*81	300LM	85V-265V	
JL171110- 6W IP65	6W	DARK GRAY	3000K	80*70*142	600LM	85V-265V	
JL171110- 3W IP65	3W	DARK GRAY	3000K	79*68*80	300LM	85V-265V	
JLW1710YS 2X3W IP65	6W	DARK GRAY	3000K	160*80*55	600LM	85V-265V	
JLW9020 6*1W	6W	BLACK	3000K	170*80*50	600LM	85V-265V	
JLW1710SA- 2X7W IP65	14W	BLACK	3000K	175*110*50	1400LM	85V-265V	
JLW1710S- 12W IP65	12W	DARK GRAY	3000K	175*90*30	1200LM	85V-265V	
JLWS1711 8W	8W	WHITE	3000K	150*150	800LM	85V-265V	
JLWR1711 8W	8W	WHITE	3000K	150	800LM	85V-265V	

### Installation instructions:

1. Turn off the electricity.
2. Cut the hole in its diameter.
3. Connect cables to the gear.
4. Press in the spring loaded arms and pull them up through the hole. The springs will pull the fixture up towards the ceiling.
5. turn on the electricity.
6. lamp works normally.



### WARNING!

1. Cut off power before installation.
2. Can not be used as emergency light.
3. Nothing should cover the product.
4. The environment temperature of the lamp operation is  $-10^{\circ}\text{C}$  to  $+40^{\circ}\text{C}$ .