


Solar Flood lighting

Product installation instructions




Remote Control Description



Note:once the ON/OFF button is pressed,the light control is colsed.If you want to switch on in the evening.You need to press the AUTO button to activate the light.Otherwise solar panels will not start lighting at night auomatically

Packing list



Installation instruction

1. Using 2 screws pin up the lamp to the wall
2. The solar light can be adjusted as your request.
3. Lamps can not be installed in low-lying areas to avoid soaking water.
4. Insert the plugs and tighten the waterproof button cap to complete the installation.
5. Check it after connection
 - ①Check whether the installation has been fixed.
 - ②Detecting the lamp using the remote control.
6. Instructions
 - ①Pressing the Auto button to turn on the light. Then connect solar panel and solar lamp.
 - ②Automatic light control by tightening the waterproof cover.

Important Reminder:

- 1.Please do not connect the solar panel exceed 6V to avoid solar light damage
- 2.Please do not connect 220V AC.
3. Please pay attention to fixing the solar panels to avoid falling and hurt people.
- 4.Please do not disassemble the solar light to avoid affecting maintenance.
5. In order not to affect The use of solar lamp the dust and debris on the surface of the solar panel are cleaned every 3 months.
- 6.Please check regularly if the thread ends are missing or broken.
- 7.The solar light contains a battery, and the battery is recyclable. Please don't throw it.
- 8.The battery should be fully charged,Then can use more than 12h.
- 9.Please install the solar panel under sufficient sunlight to facilitate battery charging.
The best charging time of the day is from noontime to nightfa